

## FTP, SSH Instructions

---

As You know, AzBox HD is Linux based receiver, so FTP and SSH are supported.

For the beginning You need to know that AzBox HD use secure FTP protocol, so u always use to connect by ftp on port 22. !!!!!!!!!!!!!And not port 21 like other receivers!!!!!!!!!!!!!!

Example in FilleZilla You put this :

Host: IP address of Receiver Username: root Password: azbox Port: 22

For SSH access to AzBox HD You can use free Putty client which i added in attachment of this post.

For example:

In field Host Name ( or IP address ) : Here enter IP address of Receiver

And click on Open, soon it will be prompted to enter Username ( Username is root ), and after that Password ( Password is azbox ).